

CONTENT



EACH PACK CONTAINS THE FOLLOWING:

- A pair of Window Aprons sunshades – one for left side and one for right side, marked on the label.
- 10+ pieces Velcro hooks reinforced with self-adhesive tape.
- Extra packet of reinforced Velcro for future replacement.

Please note: Window Aprons are custom made to fit the shape of the rear vehicle window opening and the label is on the interior.

STEP 1



Fully open the rear door of the vehicle and clean both lateral sides of the surfaces behind the weather strap (black rubber) to be bonded and ensure the surfaces are dry and free from dust, oil and grease.

STEP 2



Attach the Velcro hooks to the corresponding Velcro loops on the sunshade.

Attach Velcro hooks to the corresponding Velcro loops on the sunshade as follows:

- Long velcro hooks straight with the corresponding long velcro loops
- Short velcro hooks cross with corresponding short velcro loops

STEP 3



Stretch the Window Aprons™ sun shade from the top corner and slide the stretched elastic thickener between the weather strap (i.e. black rubber fitted on the inside of the rear door frame) and the door frame. Move down the lateral side in line with the weather strap shape and attach the Velcro to the section of the door where it provides the perfect fit for the Window Apron™.

STEP 4



Stretch and move the top of the Window Apron™ to the opposite top side by sliding it between the weather strap and the door frame. Then slide down the lateral side of the door frame. Adjust for perfect alignment and neatness. **NB:** Where the weather strap at the top corner is not strong enough to hold the Window Apron™, the top corner Velcro hook/s should be attached to provide the support.

STEP 5



Attach the remaining Velcro hooks on the sides to the inside section of the door frame where it provides the perfect fit for the Window Apron™.

Adjust for neatness.

STEP 6



Gently remove the sunshades by detaching the Velcro loops and leave the attached Velcro hooks. Apply firm pressure to the attached Velcro hooks on the door frame to ensure the glue sets properly. Please allow 24 hours for the glue to cure.

Now you can fit and remove the sunshades as and when the need arises.

Fitting Instructions:

Follow steps 3, 4 and 5 above except that the Velcro hooks are already attached to the door frame.

Removal Instructions:

Follow step 6 above.

Instructions before car wash:

- Please remove your Window Aprons™ sunshades before taking your car for washing.
- This is to avoid any damage that may be caused by people who don't know how to remove and refit it.
- The Velcro hook/s attached to the door lifts a bit after a while, if this happens, apply firm pressure to reattach on the door frame.

- This will help to prolong the lifespan of both the sunshades and the attached Velcro hooks on the door frame.
- Iron it to remove creases to look flat.

Reinforced Velcro hook replacements available in store.